

LED Mirror User & Installation Manual

Thank you for choosing our premium LED mirror. Please read this manual carefully before installation and operation.

IMPORTANT SAFETY WARNING

In New Zealand, all electrical installations and hardwiring must be carried out by a Registered Electrician in accordance with AS/NZS 3000 wiring rules. Do not attempt to install the electrical components yourself.

1. Installation Guide (Z-Bar / Cleat System)

Please ensure the wall is capable of supporting the weight of the mirror.


Step-by-Step Installation:

Measure & Mark: Measure the distance of the pre-installed Z-bar (cleat) on the back of the mirror. Mark the corresponding position (the edge line) on the wall using a pencil.

Level & Secure the Wall Cleat: Place the wall-mounting Z-bar against your mark. Use a spirit level to ensure it is perfectly horizontal. Secure the Z-bar firmly to the wall using appropriate screws and wall anchors.

Hang the Mirror: Carefully lift the mirror and slide the bracket on the back of the mirror down onto the wall-mounted Z-bar as shown in the diagram. Ensure the two pieces interlock securely.

2. Touch Switch Operation Instructions



3.

The mirror features an intuitive touch-sensor control panel with three main functions.

Radar Sensor (Motion Sensor)

Radar Signal Window: This area detects motion and serves as the function indicator.

To Turn On/Off: Touch the Antifog button twice to activate or deactivate the radar function. When activated, the radar indicator light will illuminate.

LED Lighting Control

Touch Once: Turn the LED light On / Off.

Touch Twice (or Cycle): Change the color temperature between 3000K (Warm White) → 4500K (Natural White) → 6000K (Cool White).

Long Press: Adjust the brightness (Dimming function).

Antifog (Demister)

Touch Once: Turn the antifog function On / Off.

Technical Specifications

Compliance: Conforms to AS/NZS electrical safety standards.

Application: Suitable for bathroom use (ensure local IP rating requirements are met based on the installation zone).